

Advance purge cleaner is for use once the spent oil has been removed from the die temperature control unit.

Prior to filling with new heat transfer fluid, it is desirable to clean the temperature control unit with purge cleaner. Simply put the cleaner in the oil unit and run for 24 hours, then drain the cleaner and install fresh oil. Our purge cleaner is available in 5 gallon pails and 55 gallon drums.